

Hanging Baffle Installation

ECHO ABSORBER™ Acoustic Baffle

Tools and Materials Needed

- 2 - 1 1/2 in. Screw Eyes
- 2 - Lengths of light duty chain.
- 4 - S Hooks
- Tape Measure and a Pencil
- 24 in. Level

Step 1

Note:

These instructions were created for the installation of ECHO ABSORBER™ Acoustic Baffles with the dimensions of 2 ft. X 4 ft. One can adapt these instructions for a variety of sizes and applications. ECHO ABSORBER Acoustic Baffles can be hung at any desired height and should be placed 24 in. to 36 in. apart. The use of Plastic Anchors may be required when hanging this product from a Drywall or Concrete ceiling. The Eye Screws are not required when hanging this product from steel trusses. Use our instructions as a general guide. To cut, lay the material on a flat clean surface. Compress the material with a straight edge or level and cut with a sharp utility knife. For a quick cut, use a 6 1/2 in. Framing saw.

1) Install the first Screw Eye. Measure 40 in. and place the second Screw Eye.

2) Cut the light duty chain to the desired length and install it to the first Screw Eye with a S Hook. Use another S Hook to attach the other end of the chain to the ECHO ABSORBER™ Acoustic Baffle. Repeat the process for the next section of chain. Use the 24 in. Level to fine tune the height so the baffle hangs level.

