

# STEP ABOVE™ Installation Instructions

## Tools and Materials Needed

- Utility Knife
- 4 ft. Straight Edge
- Adhesive Tape

### Step 1

Subfloor surface must be clean and dry before installation.



### Step 2

Start in a corner. Unroll STEP ABOVE™ flooring underlayment over the subfloor with the vapor barrier film side down. Be sure the tape strip side is next to the wall and overlapping lip is toward the open room.



### Step 3

Roll out the next row in the same manner. Butt the underlayment close to the first row, overlapping the moisture barrier lip. Be sure to overlap the vapor barrier lip and not the underlayment material.



#### Step 4

Remove the tape liner from the bottom of the underlayment and secure it to the vapor barrier lip of the a joining piece. Continue this process untill installation is complete. Seal all open seams with an aggressive adhesive plastic tape.



#### Step 5

Install flooring per manufacturers instructions.

