

Installation Instructions:



Stud / Beam Isolators

Note: Calculate the amount of pieces needed by multiplying your total square footage by .85. For example a floor 20 ft. x 20 ft. will require 340 isolators.

STEP 1

Friction fit the first piece over the joist, no more than 6 in. from the end.

STEP 2

Install the rest of the pieces on the joist, spaced at 12 in. to 24 in. gaps, based on the floor length and load it will support.

STEP 3

Repeat steps 1 and 2 for each joist. The final piece should again be no more than 6 in. from the end of the joist.

