

## mounting instructions – Anechoic Baffle studio foam

These instructions are intended to serve as a guide only. The responsibility for recognizing and compensating for field conditions is with the installer. The use of plastic anchors may be required when hanging baffles from a drywall or concrete ceiling. The eye hooks are not required when hanging this product from steel trusses.

### tools & materials

tools: pliers, level, tape measure and pencil (drill, drill bits and plastic anchors may be required for drywall and concrete installations)

materials needed: eye hooks, chain and S hooks

### installation steps

- 1) Layout baffle location across the ceiling. Draw reference lines where necessary.
- 2) Locate where first eye hook will be located and install.
- 3) Measure 36 inches and install the second eye hook.
- 4) Confirm measurements before installing.
- 5) Pull the chain through the eye hook and crimp the S hook with pliers, bonding the chain links together.
- 6) Pull the other end of the chain through the grommet tabs of the baffle and crimp another S hook at desired hanging height.
- 7) Using a level as a guide, repeat the process for the other grommet tab.
- 8) To complete the installation, trim the excess chain with pliers.

