

general installation and mounting tips – studio foams

- Avoid excessive handling of studio foam products. The more they are handled, the greater the chance for damage.
- Class A foams are fragile and should be handled with care.
- Avoid contact with sharp objects or edges.
- Generally, studio foams are not recommended for high impact areas.
- If the panels are installed on a wall that is not plumb, misalignment will be apparent. Care should be taken in laying out panel placement and in preparing the wall surface before installation. A majority of installation problems occur due to the lack of preparation prior to installation.
- Ambient light conditions can cause shadowing, magnifying even the slightest misalignment.
- Never install our panels without the provided leveling brackets. The leveling brackets are the main load bearing support while the adhesive cures.
- Use a level reference line when installing the leveling angles to ensure the studio foam panels end up being level.
- When installing the panels with adhesive, consider using temporary brackets to hold the panels in place while the adhesive cures. Most adhesives achieve a full cure within a 24 hour period of time, depending on ambient temperature & humidity.